


# Storm 100

## Exploded parts diagram








Part Number	Number	Description	Qty
***	1	Cutlery Basket	2
B8-12024990	2	Plate Basket	1
B8-12025011	3	Plastic Glass Basket	1
***	4	Complete Basket Base	1
***	5	Basket Guide	1
***	6	Damper	2
***	7	Right Side Panel	1
***	-	Left Side Panel	1
***	8	Front Panel	1
***	9	Complete Frame	1
***	10	Adjustable Leg	4
***	11	Front Filter Guide	1
***	12	Filter	1
***	13	Rear Filter Guide	1
***	14	Complete Tray	1
***	15	Waste Collection	1
***	16	Rear Panel	1


\*\*\*Please contact Spares for assistance\*\*\*





Part Number	Number	Description	Qty
***	1	Complete Hood	1
B8-12024303	2	Magnet	1
***	3	Door Handle	1
***	4	Rotary Shaft	2
***	5	Bearing	2
***	6	Washer	2
***	7	Complete Rocker Arm	1
***	-	Washer	2
***	-	Lock Washer	2
***	-	M8 SS Nut	2
***	8	Spring Cover	1
***	9	Hood Support Seal	4
***	-	Screw	10
***	-	Hex Chrome Screw	4
***	-	Washer	14
***	-	Lock Washer	14
***	-	M8 SS Nut	10
***	10	Hood Guide Support	2
***	11	Revolving Bushing	4
***	-	Safety Washer	8
***	12	Complete Hood Guide	1
***	13	Bushing	2
***	14	Hex Bolt	2
***	15	Tensioning Spring	2
***	16	Spring	2


\*\*\*Please contact Spares for assistance\*\*\*





Part Number	Number	Description	Qty
B8-12043287	1	Pipe Elbow	1
***	2	Clamp	8
***	3	Wall Bush Nut	1
B8-12009960	4	Washer	1
***	5	Prewash Bush	1
***	-	O Ring	1
B8-12006587	6	Wash Pipe with Welded Support	1
B8-12024934	7	Upper Distributor Support	1
***	8	Left Rinse Branch	2
B8-12024470	9	Rinse Branch Support	2
B8-12009829	10	Rinse Arm Securing Bolt	2
***	11	Right Rinse Branch	2
B8-12024077	12	Rinse Jet	12
B8-12024006	-	Rinse Jet Clip	12
B8-12009912	-	Rinse Jet Seal	12
***	13	Special Nut	2
***	14	Bush	2
***	15	Wash Arm	2
***	16	Washer	2
***	17	Central Shaft	2
***	18	Lower Support	1
***	19	Seal	1
***	20	O Ring	1
***	21	O Ring	1
***	22	Bush	1
***	23	Pipe	1
***	24	Motor Support Bracket	1
***	25	Wash Pump Base	2
B8-12043287	26	Wash Pump	2
***	27	Capacitor	2
***	28	Extractor Pipe	2
***	29	Wall Bush Nut	2
B8-12009960	30	Washer	2
***	31	Extractor Bush	2
***	32	Rear Motor Support Bracket	1
***	33	Detergent Wall Bush	1
B8-12133011	34	Detergent Dispenser	1
***	35	Aspiration Hose	1
***	36	Filter Weight	1
***	37	Conduit	1

\*\*\*Please contact Spares for assistance\*\*\*








Part Number	Number	Description	Qty
***	1	Overflow	1
B8-12010165	2	Drain Plug Seal	1
***	3	Drain Bush	1
***	4	Washer	1
***	5	Grooved Nut	1
***	6	Clamp	1
B8-12024473	7	Drain Hose	1


\*\*\*Please contact Spares for assistance\*\*\*





Part Number	Number	Description	Qty
***	1	Overflow	1
***	2	Drain Bush	1
***	3	Grooved Nut	1
***	4	Hood Accumulator	1
***	5	Drain Hose	1
B8-12023456	6	Drain Pump	1
***	7	Pump Support	1
***	-	Washer	2
***	-	Hex Screw	1
***	-	Curved Screw	12
***	-	Washer	1
***	8	Pump Protection	1


\*\*\*Please contact Spares for assistance\*\*\*





Part Number	Number	Description	Qty
***	1	Upper Support	1
B8-12025161	2	O Ring	4
***	3	Nut	4
***	4	Pipe	1
***	5	Rinse Bush	3
***	6	Seal	3
***	7	Hex Nut	3
***	8	Clamp	16
***	9	Y Fitting	1
***	10	Y Fitting	1
***	11	Y Tank Feedthrough Hose	1
***	12	Tank Lower Feedthrough	1
***	13	T Fitting	1
***	14	Rinse Outlet Hose	1
***	15	Clamp	2
B8-12133010	16	Rinse Aid Dispenser	1
***	17	Blue Pipe	1
***	18	Filter Weight	1
***	19	T Fitting Boiler Hose	1
***	20	Hex Screw	1
***	21	O Ring	1
***	22	Complete Drum	1
***	23	Boiler Y Fitting Hose	1
***	24	Solenoid Valve Bracket	1
B8-12025161	25	Water Inlet Valve	1
***	26	EV- Tank Feed	1
***	27	Connection Pipe	1
***	28	Non-Return Hose	2
B8-12024077	29	Non-Return Valve	1
***	30	Water Input Hose	1
***	31	WMKA Valve (Australia)	1

\*\*\*Please contact Spares for assistance\*\*\*






Part Number	Number	Description	Qty
***	1	Water Input Hose	1
***	-	WMKA Valve (Australia)	1
***	2	Inner Regulator	4
***	3	Solenoid Bracket	1
B8-12025161	4	Water Inlet Valve	3
***	5	Clamp	3
***	6	EV- Feedthrough Conduit	3
***	7	Rinse Bushing	16
***	-	O Ring	1
***	-	Seal	1
***	-	Hex Nut	1
***	8	Nut	1
***	9	Water Intake Pipe	1
***	10	Bushing	1
***	11	BT – Presostat Hose	2
***	-	Seal	1
***	-	Feedthrough – Presostat Hose	1
***	12	Feedthrough 1- BT Hose	1
***	13	Break Tank	1
***	14	Break Tank Gasket	1
***	15	Break Tank Nut	1
***	16	BT- Conduit	1
***	-	Clamp	1
***	17	Adapter Hood Break Tank	1
***	18	Prewash Bush	1
***	-	Washer	1
***	-	O ring	1
***	-	Clamp	1
***	19	Bush Nut	1
***	20	BT-FT Conduit Hood	1
***	21	Feedthrough – BT Steam Hood	1
***	22	Rinse Pipe	1
***	-	O Ring	1
***	23	Nut	1
***	24	Rinse Bush	1
***	-	Nut	1
***	-	Gasket	1
***	25	Boiler Feed Steam Hose	1
***	26	Capacitor	1
***	27	Motor Pump Support	1
***	28	Rubber Profile	2

B8-12023429	29	Rinse Pump	1
***	30	Top Conduit	1
***	31	Booster Inlet Conduit	1
***	32	Reducer	1
***	33	Rinse Pump Feedthrough Hose	1
***	34	Bush	1
***	35	Lower Rinse Hose 1	1
***	36	Rinse Pipe	1
***	37	Lower Rinse Hose 2	1
***	38	Rinse Branch	1
***	39	Nut	1
***	40	O Ring	1
***	41	Support	1
***	42	Rinse Dispenser Hose	1
***	43	Square Boiler	1
***	44	Electric Rinse Dispenser	1
***	45	Rinse Suction Conduit	1
B8-12164632	46	Filter Weight	1

\*\*\*Please contact Spares for assistance\*\*\*







Part Number	Number	Description	Qty
	1	Switch Support	1
***	2	Magnetic Switch Fastener	1
B8-12024477	3	Magnetic Door Switch	1
B8-12008750	4	Timer PCB	1
B8-12009873	5	Support Panel	1
***	6	Fascia	1
B8-12220785	7	5V Green Led Light	1
B8-12216541	8	Power On/Off Button (Pre Nov.19)	1
B8-12171804	8	Power On/Off Button (After Nov.19)	1
B8-12216540	9	Short Cycle Push Button (Pre Nov.19)	1
B8-12171805	9	Short Cycle Push Button (After Nov.19)	1
B8-12216519	10	Medium Cycle Push Button (Pre Nov.19)	1
B8-12171806	10	Medium Cycle Push Button (After Nov.19)	1
B8-12216518	11	Long Cycle Push Button (Pre Nov.19)	1
B8-12183262	11	Long Cycle Push Button (After Nov.19)	1
***	12	Fan Protection	1
***	13	Fan	1
***	14	Rinse Tank Heater	1
B8-12010051	15	Rinse Tank Heater Seal	1
***	16	Temp. Display Sensor	2
***	17	Tank Heater	1
***	18	Tank Resistor	1
B8-12023804	19	Pressure Switch	1
***	20	BT 2 Pressure Switch	1
***	21	Limiter Fastening	1
***	22	Booster Cut-out Thermostat	1
B8-12024222	23	Pressure Switch Bolt	1
B8-12009873	24	O Ring for Pressure Chamber	3
B8-12024157	25	Pressure Switch Connex	1
B8-12024350	26	Pressure Chamber	1
***	27	Pressure Switch Hose	1
***	28	Y Connection	1
***	29	Pressure Switch Support	1
B8-12023804	30	Pressure Switch	1
***	31	Safety Pressure Switch	1
B8-12096597	32	Cut out Thermostat 110°C	2
B8-12134992	33	Thermostat 27-85°C	1
***	34	Thermostat 60°C	1
***	35	Electric Panel	1
***	36	Terminal 16	3

***	-	Step Terminal	1
***	-	Earth Terminal	1
***	-	Fuse Holder	2
***	-	Fuse 0.5A	2
***	-	Terminal Block	1
***	-	Tier	1
***	-	Terminal	5
***	-	Connector	1
***	-	Terminal Stopper	1
***	-	Capacitor	4
***		Signal 1	1
***	37	Wire Holder	1
***	-	Feedthrough Nut	1
B8-12111795	38	Contactor	2
B8-12024011	39	Contactor	1
***	40	Contactor	1
***	41	Auxiliary Contactor	1

\*\*\* Please contact Spares for assistance\*\*\*